



1. INSTALL FIRST DRIP LOOP 9-INCHES FROM CENTER OF TREE TRUNK.

INSTALL EACH ADDITIONAL LOOP PER MANUFACTURER INSTALLATION GUIDELINES.

2. INSTALL DRIP LINE TUBING ON SURFACE TO A MAXIMUM OF 6-INCHES BELOW GRADE, STAPLE IN PLACE PER MANUFACTURER'S RECOMMENDATION,

BY OTHERS.

3. INSTALL DRIP LINE IN ACCORDANCE WITH MANUFACTURER INSTALLATION GUIDELINES.

BACKFILL, AND SPREAD SURFACE TREATMENT AS DIRECTED

DRIP LINE WITH CHECK VALVE THREE RING DETAIL

CITY OF TULSA, OKLAHOMA ENGINEERING SERVICES DEPARTMENT

DRAWN BY: R.M.O.
CHECKED BY: HAS
DATE: MARCH 2022

NOT TO SCALE

STANDARD NO. 845